

# **Communication-DTM**

**Profibus Communication-DTM for FDT**

## Communication-DTM Profibus Communication-DTM for FDT

Version: 1.6  
Datum: 05. August 2004  
Best.-Nr: 4000-S-L M 7 -3

COMSOFT GmbH  
Wachhausstraße 5a  
D-76227 Karlsruhe

Telefon: +49/ 721/ 9497- 0  
Fax-Hotline: +49/ 721/ 9497- 299  
Email: [support@comsoft.de](mailto:support@comsoft.de)  
Internetadresse: [www.comsoft.de](http://www.comsoft.de)

This documentation has been drawn up carefully but, in spite of all efforts, errors may occur. Information from the part of our customers that will help to improve comprehensibility of the document and remove errors will be appreciated. The information contained therein can be amended without prior notice and does not represent any obligation on the part of COMSOFT. We do not assume any kind of responsibility for possible inconsistencies and their consequences.

# Contents

<b>1 Introduction .....</b>	<b>1</b>
1.1 Important indications .....	1
1.2 Installation of software.....	1
1.2.1 System requirements.....	1
1.2.2 Uninstall the software.....	2
1.3 Installation of hardware.....	2
1.3.1 System requirements.....	2
1.4 Co-operation of soft- and hardware.....	3
1.5 Usage in the frame application.....	3
1.5.1 Bus Parameter .....	6
1.5.2 Select another hardware .....	8
1.5.3 Profibus Service SetSlaveAddress.....	8
1.5.4 Additional functions .....	10
1.5.4.1 Installation Instructions .....	10
1.5.4.2 Bus Scan.....	11
1.5.4.3 Set Profibus Address for a Slave in Container.....	11
1.6 Data exchange with the Communication DTM .....	12
<b>2 : FAQ.....</b>	<b>14</b>
<b>3 Status- and Error message.....</b>	<b>15</b>
3.1 Profibus-Errors .....	15
3.1.1 DPV1-Error message .....	15
3.1.1.1 Error Decode .....	15
3.1.1.2 Error Code 1 and 2 .....	16
3.1.1.3 Instance und Reason Code of Abort (1.Byte) .....	17
3.2 FNL-Error message .....	18
3.3 Error- and Status message DF PROFI-Baugruppe.....	20
<b>4 Attachment.....</b>	<b>25</b>

## List of Tables

Table 1: Function- and Errorcode of DPV1 .....	15
Table 2: Error Decode.....	15
Table 3: Acceptation of Error Decode.....	15
Table 4: Error Decode 1 and 2 .....	16
Table 5: Error Code DPV1.....	16
Table 6: Instance- and Reason-Code of ABORT.....	17
Table 7: Instance .....	17
Table 8: ReasonCode for MSAC_C2.....	17
Table 9: Event-Codes FNL.....	18
Table 10: Error identifier FNL.....	19
Table 11: Boardtreibermeldungen DF PROFI.....	22
Table 12: Protocol driver message of DF PROFI.....	24

## List of Figures

Figure 1: FDT – Communication schema.....	3
Figure 2: Device catalogue of the PACTWare- Frame Aoolication.....	4
Figure 3: PactWARE: "Add device" .....	4
Figure 4: List of communication devices in Pactware .....	5
Figure 5: Selection-Box of FNLs .....	5
Figure 6: Right mouse button menue in PACTWare .....	6
Figure 7: Configurator.....	6
Figure 8: Select another hardware .....	8
Figure 9: SetSlaveAddress Menu.....	8
Figure 10: Profibus service SetSlaveAddress .....	9
Figure 11: Right mause button menu in PACTWare.....	10
Figure 12: Bus Scan Result.....	11
Figure 13: Set Profibus Slave Address .....	11
Figure 14: PactWARE: Connection between the DTMs.....	12
Figure 15: Example of an error message .....	13
Figure 16: Progress bar .....	13
Figure 17: Comsoft CONFIGURATOR .....	25

# 1 Introduction

## 1.1 Important indications

The Communication-DTM for the FNL and the DF\_Profi was tested in the listet FDT-Container-programms:

- PactWARE of the PactWARE-group
- Fieldcare of Endress & Hauser
- FdtContainer of M&M Software

We don't guarantee at this time a proper operation in other frame applications.

The Communication-DTM operates with FDT-specification 1.2a.

The Communication-DTM of Comsoft supports only DP-Master class 2 operation mode with Profibus DPV1 services.

## 1.2 Installation of software

Log in with administrator rights under Windows NT/2000/XP.

The installation is started by a double-click on Setup.exe.

During the setup of the Communication-DTM all components will be registered. The FDT-Frame-Application identifies the installed DTMs by special keys in the registry.

All upcoming registration errors during installation, if for instance a dll could not be registered, anticipate the proper operation of the Communication-DTM .

### 1.2.1 System requirements

To run the DTM properly, the following prerequisites have to be fulfilled

- Windows NT 4.0 with Service Pack 2 or better or Windows 2000/XP.
- The Internetexplorer Version 6

Windows 95/98/ME is not supported.

## 1.2.2 Uninstall the software

If you want to use the Communication-DTM later on, please bring the license back to the disk, before uninstalling.

The DTM can be uninstalled by using the uninstall button under Setting \ System Control \ Software. Please do not delete the installation path before uninstalling the software.

## 1.3 Installation of hardware

The hardware installation of the FNLs is described in detail in a separate manual called “FNL (Fieldbus Network Link) installation instructions”. Also for the different versions of the DF\_Profi board, separate instruction manuals are available.

The proper installation of the hardware is an important prerequisite for the smoothly operation of the Communication DTM.

### 1.3.1 System requirements

At minimum a computer with Pentium II 200 MHz processor or better, XGA Graphics and a Microsoft compatible mouse or an equivalent pointing device is required.

## 1.4 Co-operation of soft- and hardware

In FDT the hardware is recreated logically in software.




Figure 1: FDT – Communication schema

The data transfer with FDT is not adapted for fast cyclic services. Because of this, the Communication-DTM works as DP-Master class 2 and provides only Profibus DPV1 services to the DP-Slaves. In the frame application it is only possible to use Profibus DP-Slaves with the Communication-DTM, which also provide acyclic DPV1-services.

The user interface of the DP-Slave-DTMs is on one hand used to configure the DP-Slaves and on the other to observe the parameters and functions of the DP-Slave.

The user interface implemented in the Comsoft Communication-DTM is used to configure the master and to set the bus parameter. There are standard parameter for every Baudrate but they could be changed by the user.

## 1.5 Usage in the frame application

The COMSOFT-Communication-DTM should appear in the Device catalogue after installation. If it does not appear, the Device catalogue must be reinitialized.




Figure 2: Device catalogue of the PACTWare- Frame Application

The maximum number of FNLs or DF\_PROFI boards to be operated on one PC is limited to 8. It is not possible to use FNLs and a DF-PROFI device at the same time in one frame application. For each device a separate Communication-DTM must be opened.

To activate the Communication-DTM it must be inserted below the Host PC symbol in the frame applications project window. In Pactware the Add-Button of the device catalogue, or the “Add device” function of the Host PC’s right mouse button menu can be used. This is normally the easier way, because only suitable devices are listed, e.g. for the Profibus Communication-DTM only Profibus compatible DP-Slave-DTMs are selectable.




Figure 3: PactWARE: "Add device"




Figure 4: List of communication devices in Pactware

Here the user has to select the Communication DTM for the hardware.

Depending on the type of hardware a list of the installed devices will appear, so the user can select the one he will work with at this moment. If there is only one type of hardware installed this will automatically be used and the dialog will not appear.



Figure 5: Selection-Box of FNLs

If the selected device is already in use, an error message is shown. If this happens the Communication-DTM must be deleted and loaded once more after closing the other application. In some cases the board itself must get a Reset. This is done by switching off the power supply of the device (FNL).

In the frame application the DP-Slaves to communicate with must be added below the Communication-DTM. This is done in the same way as for the Communication-DTM (via the device catalog or the right mouse button menu). Additional Communication-DTMs can be added directly below the host-PC.

### 1.5.1 Bus Parameter

For a proper communication between DP-Master and DP-Slave, the Profibus must be configured. This is carried out by the window Bus Parameter, which can be activated via the right mouse button menu of the Communication-DTM.




Figure 6: Right mouse button menu in PACTWare




Figure 7: Configurator

Here the user can give a Profibus address to the master and change the baudrate and the parameters. By pressing the “Save data”-button the parameters are set to the DTM.

On connection the bus parameters will set to the Profibus master. If the connection is on, the “Bus Parameter” mask could not be changed.

For initiate the Slaves here are the parameter listed, which are used:

Parameters Initiate	Wert
Send timeout	2000 *10ms
Feature supported	0x01 00
Profile feature supported	0x00 00
Profile ident	0x0000
S_Add	0x00
S_len	0x02
D_Add	0x00
D_len	0x02

Table 1: Standard parameter for Initiate

Parameters Abort	Wert
Subnet	0x00
Reason	0x32
Additional Detail	0x00

Table 2: Standard parameters for Abort

The c\_ref for the slaves is build inside the communication-DTM. The data length of the Profibus READ function is set for every slave to the slave specific parameter MaxDataLen witch were send back to the master on Initiate function. For the Profibus header we differ four bytes.

If there is a DP-Master class 1 connected to the bus, the bus parameters for the Communication-DTM must be identical to that of the DP-Master class ,1 except the bus address. Otherwise the Master class 2 can not be accepted on the bus.

### 1.5.2 Select another hardware

Over the menu another hardware can be used, if there are at minimum two different once. The selection mask known from adding the DTM will be shown.




Figure 8: Select another hardware

### 1.5.3 Profibus Service SetSlaveAddress

The Profibus address of a device can set over Profibus as well. To do so the device-DTM must be added to the Communication-DTM and the Connection must exist. Over the menu on “Online parameter – Set Slave Address (profibus sevice)” this function can be started.




Figure 9: SetSlaveAddress Menu




Figure 10: Profibus service SetSlaveAddress

The dialog shows all Slaves, added on the Communication-DTM in the Container. Now one DTM can be selected. Set the actual address and the new one and press button. There is a possibility, that the slave can afterwards not set the slave address again. Now the Communication-DTM make a SlaveDiag to the actual address to get the right ident-number. This is used in the next Service, SetSlaveAddress. Afterward an SlaveDiag for testing the new address will be made. The status shows, if address could be changed. If it was successful, the device-DTM will get a notification that the slave address was changed. Because of this the Container afterwards has the really slave address.

## 1.5.4 Additional functions




Figure 11: Right mouse button menu in PACTWare

### 1.5.4.1 Installation Instructions

The installation instructions for the hardware can be found either in the installation directory of the Communication-DTM or in the frame application in the right mouse button menu within the additional functions.

### 1.5.4.2 Bus Scan

In some containers the user can find there a Bus Scan. With this function you can look for the bus addresses of the slaves which are set on the hardware.




Figure 12: Bus Scan Result

### 1.5.4.3 Set Profibus Address for a Slave in Container

With the entry “Set slave address” you can set a new Profibus address to a slave. In the Windows there is a choicebox with all slaves depending on the Communication-DTM and there actual address.



Figure 13: Set Profibus Slave Address

## 1.6 Data exchange with the Communication DTM

If a DP-Slave-DTM wants to exchange data with its appropriate DP-Slave hardware it must be connected to a Communication-DTM. In some frame applications this is done by setting the DP-Slave online.




Figure 14: PactWARE: Connection between the DTMs

Now the DTMs can communicate via FTD. During a parameter download or upload data are directly exchanged with the hardware device. In this case the Communication-DTM will work as a translator between Profibus data services and the FDT-communication.

If errors appear in the Profibus communication, they will be indicated to the user in the frame application.




Figure 15: Example of an error message

The proceeding parameter download is indicated by a progress bar. The displaying of the progress bar depends on the amount of parameters. If there is only a little amount of parameters the progress bar does not appear. How much and which parameters are exchanged depends on the device-DTM, the parameters changed by the user etc.. Some DP-Slave-DTMs support an online user interface which is updated automatically in online mode. In this case the data exchange is carried out continuously as long as the online mode is active.




Figure 16: Progress bar

The more DP-Slaves are connected to one Communication-DTM the slower the communication is processed in the frame application. We would therefore recommend, especially for the upload or download mode of parameters, to reduce the amount of DP-Slaves which are in online mode to a minimum. If there are several instances of the Comsoft Communication-DTM running simultaneously in one frame application the manual disconnection of a single DP-Slave will need a longer time.

## **2 : FAQ**

### 3 Status- and Error message

#### 3.1 Profibus-Errors

##### 3.1.1 DPV1-Error message

Functions-number	Meaning	Answer	Meaning
0x57	Initiate	0xD7	Error Initiate
0x58	Abort		
0x5E	Read	0xDE	Error Read
0x5F	Write	0xDF	Error Write
0x51	Data Transport	0xD1	Error Data Transfer

Table 1: Function- and Errorcode of DPV1

##### 3.1.1.1 Error Decode

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
								Meaning Error Code

Table 2: Error Decode

##### Acception:

Error code	Meaning
0 to 127	Reserved
128	DPV1
129 to 253	Reserved
254	PROFIBUS FMS
255	HART

Table 3: Acception of Error Decode

### 3.1.1.2 Error Code 1 and 2

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
								Meaning Error Code
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	
								Meaning Error Class 2

Table 4: Error Decode 1 and 2

#### Acception:

Error Class	Meaning	Error Code	Meaning
0 to 9	Reserved		
10	Applikation	0	Read error
		1	Write error
		2	Module failure
		3 to 7	Reserved
		8	Version conflict
		9	Feature not supported
		10 to 15	User specific
11	Access	0	Invalid index
		1	Write length error
		2	Invalid slot
		3	Type conflict
		4	Invalid area
		5	State conflict
		6	Access Denied
		7	Invalid range
		8	Invalid parameter
		9	Invalid type
		10 to 15	User specific
12	Resource	0	Read contain conflict
		1	Write contain conflict
		2	Resource busy
		3	Resource unavailable
		4 to 7	Reserved
		8 to 15	User Specific
13 to 15	User specific		

Table 5: Error Code DPV1

### 3.1.1.3 Instance und Reason Code of Abort (1.Byte)

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Meaning
-----								Reason Code
--								
-----								Instance:
-								
-----								Reserved default 0
-								

Table 6: Instance- and Reason-Code of ABORT

#### Instance

Code	Meaning
00	FDL
01	MSAC_C2
10	USER
11	Reserved

Table 7: Instance

#### ReasonCode für MSAC\_C2 (1.Byte)

Reason Code	Name	Meaning
1	ABT_SE	Sequence error service not allowed in this state
2	ABT_FE	Invalid request PDU received
3	ABT_TO	Timeout of connection
4	ABT_RE	Invalid response PDU received
5	ABT_IV	Invalid service from USER
6	ABT_STO	Send timeout requested was too small
7	ABT_IA	Invalid additional address information
8	ABT_OC	Wait for FDL_DATA_Reply.con

Table 8: ReasonCode for MSAC\_C2

#### 2.Byte: Additional Detail:

If Instance-Code is MASC2 and Reason-Code is ABT\_STO, then the Send-Timeout will be set in RM\_REQ\_PDU.

### 3.2 FNL-Error message

Code	Identifier	Meaning
1	NOT_SYN	The firmware tried futile to find a correct beginning of a telegram. Perhaps the baudrate is not set correctly.
2	TIME_OUT	The firmware didn't detect a token telegram from the other DP-Master, so it will send a token to itself.
3	DUPLICATE_ADDRESS	The firmware recognized another DP-Master at the same busadress by reading token telegrams. It might be give another DP-Master with the identical station address.
4	IN_RING	The DP-Master is set to the logical token communication and received from now an regular token telegrams.
5	OUT_OF_RING	The DP-Master was unexpectedly ignored from the token transduction of its logical predecessor
7	FAULTY_TRANSCEIVER	By sending and receiving the token telegram at the same time the telegram wasn't received correctly. Probably some parts of the send/receive hardware are defect..

Table 9: Event-Codes FNL

Code	Meaning
0x9000 0000	TMG_DF_E_BASE
0x20	TMG_DATA_LOW_RECEIVED
0x30	TMG_DATA_HIGH_RECEIVED
0x9100 0000	NO_GETSENDBOX_M
0x9200 0000	NO_WAITSENDBOX_M
0x9001 0000	FKT_GET_FNL_NAMES
0x9002 0000	FKT_TEST_TMG_BOARD
0x9003 0000	FKT_LOAD_TMG
0x9004 0000	FKT_DISPATCH_TMG
0x9005 0000	FKT_LOADBUSPARAM

Code	Meaning
0x9006 0000	FKT_INITDPMMASTER
0x9007 0000	FKT_SLAVEDIAG
0x9008 0000	FKT_SETPRM
0x9009 0000	FKT_GETCFG
0x900A 0000	FKT_CHKCFG
0x900B 0000	FKT_SETSLAVEADDRESS
0x900C 0000	FKT_LOADSLAVEPARAM
0x900D 0000	FKT_STARTDPPOLLIST
0x900E 0000	FKT_STOPPOLLIST
0x900F 0000	FKT_INITOUTPUTS
0x9010 0000	FKT_CHECKOUTPUTS
0x9011 0000	FKT_GETSLAVESTATI
0x9012 0000	FKT_DATAEXCHANGEREQ
0x9013 0000	FKT_GLOBALCONTROL
0x9014 0000	FKT_GETLIVELIST
0x9015 0000	FKT_TRANSFERPOLLDATAT
0x9016 0000	FKT_RECONNECT
0x9017 0000	FKT_READINPREQ
0x9018 0000	FKT_READOUTPREQ
0x9020 0000	FKT_XINITIATE
0x9021 0000	FKT_XABORT
0x9022 0000	FKT_XREAD
0x9023 0000	FKT_XWRITE
0x9024 0000	FKT_XDATATRANSPORT
0x9000 0100	TMG_GETTMGDEVICENAMES
0x9000 0200	TMG_CONNECTBOARDEX
0x9000 0300	TMG_RESETBOARDEX
0x9000 0400	TMG_DISCONNECTBOARDEX
0x9000 0500	TMG_GETPROCESSIMAGEPOINTERE X
0x9000 0600	TMG_BOARDHANDLE_IS:INVALID
0x9000 0700	TMG_DPR_POINTER_IS_NULL
0x9000 0800	TMG_PA_BAUD_WRONG
0x9000 0900	TMG_GETPROCESSDATAEX
0x9000 0A00	TMG_PUTPROCESSDATAEX
0x9000 0B00	TMG_GETSTATUSEX
0x9000 C100	CS_CONNECT
0x9000 0001	NO_FNL_DEFINED

Table 10: Error identifier FNL

### 3.3 Error- and Status message DF PROFI-Baugruppe

Code	Meaning
0x8000 0000	DF_E_BASE
0x8000 0001	DF_E_NO_BOARD
0x8000 0002	DF_E_LOG_INDEX_NULL
0x8000 0003	DF_E_NO_RESPONSE
0x8000 0004	DF_E_UNIT_OUT_OF_RANGE
0x8000 0010	DF_OS_LOADED
0x8000 0011	DF_OS_INSTALLED
0x8000 0012	DF_E_LOAD_OS
0x8000 0013	DF_E_NO_OS
0x8000 0014	DF_E_SERIAL
0x8000 0015	DF_E_OS:LENGTH_NULL
0x8000 0016	DF_E_OS_BUFFER_LEN
0x8000 0017	DF_E_RETURN_INFO_NULL
0x8000 0018	DF_E_BLOCK_TIMEOUT
0x8000 0020	DF_DRV_LOAD
0x8000 0021	DF_DRV_INSTALLED
0x8000 0022	DF_E_LOAD_DRV
0x8000 0023	DF_E_NO_DRIVER
0x8000 0024	DF_E_LIST
0x8000 0025	DF_E_SUB_UNIT
0x8000 0026	DF_E_LOG_UNIT
0x8000 0027	DF_E_LOG_OVERRUN
0x8000 0028	DF_E_DRV_LENGTH
0x8000 0029	DF_E_DRV_BUFFER_NULL
0x8000 002A	DF_E_OLD_VERSION
0x8000 002B	DF_E_LOG_ERROR
0x8000 002C	DF_E_DRV_INSTALLED
0x8000 0030	DF_E_CLOSED
0x8000 0031	DF_E_OPEN
0x8000 0032	DF_E_MODE
0x8000 0033	DF_E_CANCELED
0x8000 0034	DF_E_LOG_OPENED
0x8000 0035	DF_E_LOG_CLOSED
0x8000 0040	DF_E_WRITE_ACTIVE
0x8000 0041	DF_E_TX_OVERRUN
0x8000 0042	DF_E_SEND_SIZE_NULL
0x8000 0043	DF_E_WRITE_BUFFER_NULL
0x8000 0044	DF_E_RETURN_TX_NULL
0x8000 0050	DF_E_READ_ACTIVE
0x8000 0051	DF_E_RX_OVERRUN
0x8000 0052	DF_E_REC_SIZE_NULL

Code	Meaning
0x8000 0053	DF_E_READ_BUFFER_NULL
0x8000 0054	DF_E_RETURN_RX_NULL
0x8000 0055	DF_E_RECEIVED_OVERRUN
0x8000 0060	DF_E_GET_LENGTH_NULL
0x8000 0061	DF_E_GET_BUFFER_NULL
0x8000 0070	DF_E_SET_LENGTH_NULL
0x8000 0071	DF_E_SET_BUFFER_NULL
0x8000 0080	DF_DPP_LOAD
0x8000 0081	DF_E_DPP_LOAD
0x8000 0082	DF_E_DPP_NOT_FOUND
0x8000 0083	DF_E_DPP_READ
0x8000 0084	DF_E_DPP_FORMAT
0x8000 0085	DF_E_DPP_DRV_INSTALLED
0x8000 0086	DF_E_DPP_MEMORY
0x8000 0087	DF_E_DPP_SERIAL
0x8000 0088	DF_E_DPP_NOT_SUPPORTED
0x8000 0090	DF_8051_LOAD_ERROR
0x8000 0091	DF_8051_NOT_FOUND
0x8000 0092	DF_8051_LOAD_TIMEOUT
0x8000 0097	DF_8051_LOAD_8051_ACK
0x8000 0098	DF_8051_INSTALL_ACK
0x8000 0099	DF_8051_INSTALL_TIMEOUT
0x8000 00A0	DF_E_LINPAGELOCK
0x8000 00B0	DF_E_ALLOC_FAILED
0x8000 00B1	DF_E_AUTO_RECEIVE_FAILED
0x8000 00B2	DF_E_PRIVILAGE
0x8000 00B3	DF_E_BUSY
0x8000 00B4	DF_E_LOG_RX_OVERRUN
0x8000 00B5	DF_E_USER_OVERRUN
0x8000 00B6	DF_E_BUFFER_TOO_SMALL
0x8000 00B7	DF_E_RECEIVED_DISCARD
0x8000 00B8	DF_E_TRANSMIT_DISCARD
0x8000 00C0	DF_E_NO_PCIBUS
0x8000 00C1	DF_E_PCI
0x8000 00C8	DF_E_INVALID_PARAMETER
0x8000 00D1	DF_E_8051_NO_PROFI
0x8000 00D2	DF_E_8051_ALREADY_LOADED
0x8000 00D3	DF_E_8051_LOAD_ERR
0x8000 00D5	DF_E_8051_LENGTH_NULL
0x8000 00D6	DF_E_8051_BUFFER_NULL
0x8000 00D9	DF_E_8051_INSTALL_TIMEOUT
0x8000 00E0	DF_E_NO_RESET_PORT
0x8000 00E1	DF_E_OS_LOADED
0x8000 00E2	DF_E_CMD
0x8000 00F0	DF_E_WD_SIZE_WRONG
0x8000 00F1	DF_E_WD_BUFFER_NULL

Code	Meaning
0x8000 00F2	DF_E_WD_VAL_WRONG
0x8000 00F3	DF_E_WD_NOT_IN_USE
0x8000 00F4	DF_E_WD_TIMEOUT

Table 11: Boardtreibermeldungen DF PROFI

Code	Meaning	Explanation
0x00	SUCCESS, OK	Job was done successfully
0x01	WAIT_FOR_CONFIRM	Job not ended yet
0x03	MASTER_SERVICE_STILL_RUNNING	No parallel DP-Master/master functionality possible
0x04	SLAVE_SERVICE_STILL_RUNNING	No parallel DP-Master/slave-functionality possible.
0x0B	NO_HEAP_AVAILABLE	No storage of the Resource available
0x20	DL	Data low received
0x30	DH	Data high received
0x51	DP_POLL_LIST_NOT_EXISTENT	No poll-liste defined
0x52	DP_POLL_LIST_ALREADY_STOPPED	Poll-activity already stopped.
0x53	DP_POLL_LIST_TOO_LONG	Poll-liste to long
0x54	DP_POLL_DATA_LIST_TOO_LONG	Poll-daten-puffer is not correspond to the actual process figuree. Polled amount of data transcend the puffer size of the device. TX-puffer-length oversized.
0x55	DP_POLL_LIST_LEN_INCONSISTENT	TX-puffer-lrngth oversized; Number of stations different.
0x82	NR	Short acknowledgement received.
0x83	RR	No storage ressource on the partner
0x91	RDL	No storage ressource on the partner and Data low received.
0xB1	RDH	No storage ressource on the partner and Data hight received
0xC1	UE	Error on the interface of

Code	Meaning	Explanation
		the partner
0xC2	RS	SAP not active on the partner; Partner do not maintaine this fuction.; Partner do not maintaine the present state of the function; SAP reserved from another partner.
0xC3	NA	Partner don't answer
0xC4	BAD	Incorrect telegram from the partner
0xE1	NO	Function not possible in this state
0xE2	INI	Own Station not in ring, it is not initialised
0xE3	DS	Own Station not in ring or Bus separated
0xE4	IV	Incorrect parameters on function construction
0xE5	LR	Own equipment not sufficient
0xE6	LS	Ownr SAP not active
0xF1	FE	Format- error in request-telegram
0xF2	NI	Function not implemented on the partner
0xF3	AD	Access denied on the partner
0xF4	EA	Area exceeding on up-/download
0xF5	LE	Datablocklength to big at uip-/download
0xF6	RE	Format- error in answer-telegram
0xF7	IP	Faulty parmameters
0xF8	SC	Function in actual mode of operation not acceptable
0xF9	SE	Error in sequence
0xFA	NE	Area at the partner not available
0xFB	DI	Daten incomplete or incorrect
0xFC	NC	Settings of parameter not compatible on download

<b>Code</b>	<b>Meaning</b>	<b>Explanation</b>
0xFD	TO	Timeout, Time control is up

Table 12: Protocol driver message of DF PROFI

Other Errors are described in detail in the Profibus DP- or L2 protocol driver manual.

## 4 Attachment

Comsoft deliver with the Communication-DTM a separate Tool named CONFIGURATOR. It is for testing the Profibus without FDT. Here every profibus-command, Profibus DP or DPV1, can be set to a slave separate. Of cause the communication must be done above a Comsoft master. The configuration of the bus can also be done with a Comsoft master. The Tool has an online help function for better understanding.




Figure 17: Comsoft CONFIGURATOR